

Wildfire VioStorm VS-120 Trias Control Software Updating Instructions

The fixture's current software version is displayed on the home menu screen. See Fig.1




Fig. 1

To update the software, turn the fixture ON, select Confirm from the Program Update menu selection and press the UP button. The fixture will now be in Bootloader Mode waiting for the software update file. See Fig. 2




Fig. 2

Once the Bootloader Mode is invoked the fixture will turn the LED's off and wait for the software update. To exit the Bootloader Mode without installing the update, turn the fixture power switch OFF. To continue with the installation, connect the provided Mini B USB to Type A USB cable to the fixture and PC. The PC should recognize the fixture as a new USB device and install the appropriate drivers.

Open the Bootloader program (Wildfire_USB_Bootloader.exe) on the computer which should now indicate that the fixture is connected in the lower right hand corner of the screen. See Fig. 4




Fig. 4

Load the software update file into the Bootloader program by selecting the Load File button and choosing the file to be loaded (VS120_1_3.cyacd) See Fig. 5




Fig. 5

Install the update onto the fixture by selecting the Program button in the Bootloader program. The status log will indicate that the update as started and a green bar at the bottom of the screen will show the install progress. See Fig. 6




Fig. 6

Once the upload process has completed the status log will indicate that the update was successfully ended. The Bootloader program will also indicate that the fixture is now disconnected in the lower right hand corner of the screen See Fig. 7 Close the Bootloader program.




Fig. 7

Once the software installation is complete the fixture will resume its normal operation and the home menu will now display the new software version. See Fig. 8




Fig. 8

New features and fixes in this version Include:

- Added new Slow Fade effect
- Fixed error message in RDM when Device Label is edited
- Fixed error message in RDM when DMX Address is edited
- Fixed Device Model Description displayed in RDM
- Fixed Lamp State function in RDM
- Fixed Lamp Hours displayed in RDM
- Fixed Fan RPM and Temperature Sensors displayed in RDM