

LOCAL CONTROL EFFECTS CHART

WILDFIRE® TRIAS® LIGHTING CONTROL SYSTEM REV. 2.2 VIOSTORM PRO LOCAL CONTROL EFFECT SETTINGS

VioStorm Pro UV LED Lighting System
Model VSP-120

Effects Menu

Effect	Setting	Description
Off	Effects Off	All LED's static at the brightness level set on the Dimmer menu selection
Strobe	1-60	Strobes all LED's at the brightness level set on the Dimmer menu selection, at a rate adjustable from 2-12 SPS
Flash	1-60	Flashes all LED's at the brightness level set on the Dimmer menu selection, at a rate adjustable from 1-12 FPS
Pulse	1-60	Pulses all LED's at at the brightness level set on the Dimmer menu selection, at rate adjustable from 5 sec. long pulse to 4 PPS
Random	1-60	Randomly strobes all LED's at the brightness level set on the Dimmer menu selection at an adjustable rate
Slow Fade 1	1 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 2:10, ON 1:00, Fade :10, OFF 1:00
Slow Fade 2	2 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 4:10, ON 2:00, Fade :10, OFF 2:00
Slow Fade 3	3 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 6:30, ON 3:00, Fade :30, OFF 3:00
Slow Fade 4	4 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 8:30, ON 4:00, Fade :30, OFF 4:00
Slow Fade 5	5 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 10:30, ON 5:00, Fade :30, OFF 5:00
Slow Fade 6	6 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 12:30, ON 6:00, Fade :30, OFF 6:00
Slow Fade 7	7 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 14:30, ON 7:00, Fade :30, OFF 7:00
Slow Fade 8	8 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 16:30, ON 8:00, Fade :30, OFF 8:00
Slow Fade 9	9 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 18:30, ON 9:00, Fade :30, OFF 9:00
Slow Fade 10	10 Minute	Fades all LED's ON and OFF at the brightness level set on the Dimmer menu selection, Total Time 20:30, ON 10:00, Fade :30, OFF 10:00